

SW360 QUICK START GUIDE

SAFETY WALK 360

SAFETYWALK 360

SUGGESTED INSTALL LOCATIONS

TRANSMITTER



RECEIVER



STEP 1

Locate suitable area for mounting transmitter buttons on the vehicle. Mount transmitters using screws, emblem adhesive, or emblem VHB.

Remove transmitter housing top cover using 17/64 hex driver. Install new CR2032 battery.

Reattach transmitter cover screws. Tighten to 10 inch lbs (snug)

DO NOT OVERTIGHTEN.



STEP 2

Locate vehicles OBDII port. This is typically located under steering wheel. Plug in SW360 receiver to OBD-II port.

The receiver will begin to update. Once complete the receiver will sound 5-10 beeps. This update typically takes 60 seconds.

Do not proceed until this step is complete.



STEP 3

Once the receiver has finished its update, Proceed to pair the wireless transmitter buttons by simply pressing the buttons you would like to pair.

Start and operate vehicle for a short distance to assure proper operation.

INSTALLATION IS COMPLETE.

